

Module 2: Weld Measurement







Features

- Fillet weld measurement
- Setting management
- Custom parameters
- Report generation
- Measurement history



llet ×			×			
ietting: LIM W	/eld 001	s 🛃	now Drawing			
🔀 Reset		Load Setting Save	Setting As			
Parameters — Parameter	Measure	Label Limits Min.	Max.			
а						
a1	2.					
a2		Welds History ×				
		Date	Path to Image	Setting	cu: unuu lloor	
s		Wed 3/24/2016 09:55 AM	C:\Welding\\sample_08.tif	LIM Weld 001	Setting: LIM Weld 001	Show Drawing
b		Wed 3/24/2016 09:50 AM	C:\Welding\\sample_07.tif	LIM Weld 001	Parameters	
z1		Wed 3/24/2016 09:45 AM	C:\Welding\\sample_06.tif	LIM Weld 001	Parameter Value	OK / NOK Min. Max.
-7		Wed 3/24/2016 09:40 AM	C:\Welding\\sample_05.tif	LIM Weld 001	a 6.5	
22		Wed 3/24/2016 09:35 AM Wed 3/24/2016 09:30 AM	C:\Welding\\sample_04.tif	LIM Weld 001	a1 0.3	í
h1		Wed 3/24/2016 09:25 AM	C:\Welding\\sample_03.tif	LIM Weld 001	a2 1.0	1
h2		Wed 3/24/2016 09:20 AM	C:\Welding\\sample_01.tif	LIM Weld 001		
fl1					h (11	
111	<u> </u>				D 1.4	NOK 1.2
fl2					z1 4.5	
t1					z2 5.0	J
t2					h1 1.6	
					h2 1.5]
asym					ti1 3.6	OK 3.0 3.9
					fi2 3.3	OK 3.3 4.0
Lustom Paramet	ers —				t1 3.5	í
G					+2 20	i i
					2 2.0	
					asym 0.11	OK 0.2
					G	_
Allowed We	ld Shap				shape Convex	OK
🖌 Mitre	\mathbf{E}				Result	
Supporting Lines						Report
For Parameter	,					Alternative Report
ht					NON	
						Export to Excel
h2 📋			<u></u>			
fl1 🗹	min(t	1, t2) / 10 or				
fl2 🗹	min(t	t1, t2) / 10 or				
Report Templat	e ——					
Default			Change			



Measurement Definition

- 1. Weld parameters selection
- 2. Label visibility settings (labels displayed in the image or not)
- 3. Conditions parameter limits can be set
- 4. The "Show Drawing" button to display the geometry (legend)

		×	
illet ×		4	Weld Parameters Scheme ×
Setting: LIM V	Veld 001	Show Drawing	
🔀 Reset	Load Setting	1 Save Setting As	t_2 Z_1
	<u> </u>		
Darameters	Masaura Labal Lin	vita Min May	
- unumeter			
a -1			
1b 2			E I
a2			
s			
21		×	
72			
h1			
h2			
fl1		√ 3.0 3.9	
fl2		√ 3.3 4.0	
ti			
t2			
asym		☑ 0.2	
Custom Parame	ters		
G			
		Add / Hallaye	
Allowed We	eld Shapes		
Mitre	Convex	Concave	
Supporting Line For Parameter	Ratio	Distance [mm]	
h1 🗌	z1 /	or	
h2 🗌	z2 /	or	
fl1 🗹	min(t1, t2) /	10 or	
fl2 🗹	min(t1, t2) /	10 or	
Report Templa	te		
Default		Change	
History.		Start Measurement	
			1
			145





NIS-

NIKON METROLOGY STRATEGIC PARTNER

Custom Parameters Management

- 1. Click "Add / Manage..." to create new, edit or delete existing custom parameters
- 2. Select measurement method:
 - Distance from
 - Two points
 - Circle
- 3. Confirm by "OK"

Tillet	_	_		X	
Setting: LIM V	Veld 001		Show Drawing		
🔀 Reset		Load Sett			
Parameters					×
Parameter	Measure	Label I	Custom Parameters		
					+ X 🍄
a1			Name	Measure As	Reference Parameter
a2			G	Distance from	nz
s				6 D	
b				Distance from	
z1				Two points	
72				🕐 Circle	3
h1					
h2					
fl1					
fl2				1	
t1					
t2		2			OK Cancel
asym			0.2		
Custom Parame	ters				
G	$\mathbf{\mathbf{\nabla}}$	⊻			
			Add / Manage		
	eld Shape	s —			
Mitre		Convex	Concave		
C Supporting Line	s				
For Parameter		Rati	tio Distance [mm]		
h1 🗌		z1 /	or		
h2 🗌		z2 /	or		
fl1 🗹	min(t	t1, t2) /	10 or		
fl2 🗹	min(t	t1, t2) /	10 or		
Report Templa	te —				
Default			Change		
History.			Start Measurement		





Allowed Weld Shapes

- 1. "Allowed Weld Shapes" restriction
- 2. The following shapes are available:
 - Mitre
 - Convex
 - Concave

	_	_	_			
Fillet ×						
Setting: LIM V	Veld 001			Sho	w Drawing	
🔀 Reset		Load Se	etting	Save 9	Setting As	
Parameters						
Parameter	Measure	Label	Limits	Min.	Max.	
а						
al						
a2						
s						
b			\checkmark		1.2	
z1						
z2						
h1						
h2						
fl1			2	3.0	3.9	
fl2			~	3.3	4.0	
ti						
t2						
asym			\checkmark		0.2	
Custom Parameters						
G		\checkmark				
				Add / M	lanage	
	eld Shape	s				
Mitre	V	Conve	K [Concav	e	
C Supporting Line	s					
h1		z1 /	adio] or [stance [mm]	
h2		z2 /		or		
fl1 🔽	min(t1, t2)/	10	or		
fl2 🗹	min(t1, t2) /	10	or [
Report Templa	te					
Default				(Change	
History Start Measurement						





Supporting Lines

- Supporting (sw generated) lines allow to measure penetrations and fuse legs in requested distances
- Line distance from surface is defined by either Material thickness fraction or Distance in metric units

Weld Parameters Scheme ×

fl₂

Z₁

N

t,







Report Template

lements

NIS-

- Default a simple table-like report will be generated after the measurement
- Click "Change…" to select a custom template created in NIS-Elements Report
 Generator. Such a template can contain header, footer, graphics, etc.







NIS-



Setting Management

- All the weld measurement settings can be saved to a file.
- All the weld measurement settings can be loaded from the file.
- This allows the user to copy settings to other computers.







Measurement Workflow



- 1. Click "Start Measurement"
- 2. Measure the parameter highlighted in the table; the next parameter follows automatically after right-click
- 3. It is possible to move one step back
- 4. It is possible to finish the measurement before its regular end by the "Finalize" button





Results - Output

- 1. OK / NOK is displayed
- 2. Click "Report" for the standard report (defined in settings)
- 3. Click "Alternative Report" to create a different report using another template from the disk.
- 4. Click "Export to Excel" to automatically transfer the measured data into an excel sheet
- 5. Click "History…" to browse the history of measurements (see next slide)





Measurement History

- 1. Parameters of every finalized measurement is saved to a database including:
 - settings

lements

- measured data
- path to image
- reports
- 2. Measured data of the selected record are displayed on the right
- Douple click the path to open the weld image used for measurement



